

Secure4k Memory Card Upgrade Instructions

1 For easier installation Unclip from Windshield Mount

A. Firmly press camera to the left, and pull straight down.

**DO NOT REMOVE
WINDSHIELD MOUNT
FROM WINDSHILD**



2 Locate SD Card Slot

A. Located on the front of the camera.



3 Remove SD Card

A. Press the memory card gently inward until you hear or feel a click.

B. The card will pop out slightly for easy removal



4 Install Upgraded Memory Card

A. Align the new memory card with the slot, ensuring the gold contacts are facing DOWN.

B. Gently push the card into the slot until you hear or feel a click.



5 Attach to Windshield Mount

A. Align camera with windshield mount.

B. Gently press up and right to latch in place.

